USER MANUAL

Label Unwinder "All-in-one" series Label Rewinder "All-in-one" series










APPLICATIONS

Those units are used to rewind/unwind the labels coming from the input or output of color label printers onto an adjustable core holder from 40mm (1.57") up to 118mm (4.64") or onto the 76mm (3") fixed core holder. The maximum label roll diameter can be 250mm (9.84") or 300mm (11.81") and the maximum label width can be 244mm (9.60") depending on the selected model.


POWER SUPPLY

An external power supply 100/240VAC - 2.5A at 24V === allows an electronic circuit to provide, through the tension arm, the speed and sense of rotation auto adjustment.


INSTALLATION



STEP 1Unscrew the two knobs.




STEP 2Set the included printer plate beside the unit's base.




STEP 3Screw both plates with the two knobs.

HOW TO OPEN THE CORE HOLDER



Adjustable core holder



3" Fixed core holder

WORKING CONDITIONS

LABEL REWINDER "all-in-one" series:


- When the printer forwards the media for printing, the tension arm goes down, the device rewinds the media. Yellow or green led on depending on the selected rewinding mode (face-in or face-out).
- When the tension arm is in the middle position, the device is idle. Both yellow and green leds on.
- When the printer backwards the media, the tension arm goes up, the device unwinds it. Yellow or green led on depending on the selected rewinding mode (face-in or face-out).

LABEL UNWINDER "all-in-one" series:

- When the printer forwards the media for printing, the tension arm goes up, the device unwinds the media. Yellow or green led on depending on the selected rewinding mode (face-in or face-out).
- When the tension arm is in the middle position, the device is idle. Both yellow and green leds on.
- When the printer backwards the media, the tension arm goes down, the device rewinds it. Yellow or green led on depending on the selected rewinding mode (face-in or face-out).

When the unit is operating but the media is not loaded or it runs out, the tension arm reaches the lowest position and after few seconds the unit will stop by itself, both leds blink and it beeps.

CONTROL PANEL



ON-OFF

Push this button to turn On or Off the unit.

INCREASE SPEED

Push this button to increase the rotation speed.

DECREASE SPEED

Push this button to decrease the rotation speed.

LABEL FACE-OUT

<u>Turn the unit off.</u> Keep pushed "FACE OUT" button, push and release "ON-OFF" button while the green led turns on and off. The unit is now ready to operate.

LABEL FACE-IN

<u>Turn the unit off.</u> Keep pushed "FACE IN" button, push and release "ON-OFF" button while the yellow led turns on and off. The unit is now ready to operate.

SMART SOLUTIONS FOR THE LABELING INDUSTRY

Label rewinder, label unwinder, electronic label dispenser and more...

OTHER PRODUCTS



LABEL UNWINDER/REWINDER



SMALL LABEL
UNWINDER/REWINDER



LABEL COUNTER



ROLL TO ROLL SYSTEM FOR LABEL PRINTERS



ROLL TO ROLL SYSTEM FOR EPSON PRINTERS



ROLL TO ROLL SYSTEM
FOR VIPCOLOR VP SERIES



ROLL TO ROLL SYSTEM FOR PRIMERA LX SERIES



MATRIX REMOVER AND SLITTER



LONGITUDINAL LABEL SLITTER



EASY LABEL DISPENSER



ELECTRONIC LABEL DISPENSER



SCORPIO SERIES:
DIGITAL LABEL FINISHING SYSTEMS



GEMINI: Digital die Cutter for Sheets



VIRGO:
DESKTOP DIGITAL FINISHING SYSTEM



MOTORIZED CORE HOLDER Unwinder/Rewinder

- FOR MORE INFO CONTACT YOUR RESELLER -